


Singer 750 / 770
Fashion Discs

Black colored cams, or as some may refer to them as “top hat cams”



White colored cams, double layered, flexi-stitches

