


SINGER
403A

List of Parts—Machine No. 403A



Machine No. 403A






ATTACHMENT SET 161279

8879	Felt Washer (4)
51361(813)	Bed Plate Screw
51621(813)	Bed Plate Nut
81200	Rinder
161133	Tube of Oil
161166	Zipper Foot
161167	Applique Foot
161168	Button Foot
161195	Hemmer Foot
161276	Lint Brush
161278	Attachment Box
161294	Screwdriver (IG)
161295	Screwdriver (SM)
161561	Ruffler
170071-001	Presser Foot
172007	Spool Pin (3)
172185	Fashion Disc 1
172191	Fashion Disc 5
172229	Fashion Disc 6
172230 ⁴	Fashion Disc 7
172336	Robbin (plastic) (4)
174527	Fashion Disc 9
171323-174528	Fashion Disc 8
174529	Throat Plate
174533	Fashion Disc 10
174540	Fashion Disc 11
2020(15x1)	Needles 14 (3) 16 (3)



List of Parts—Machine No. 403A



NOTE: Due to accuracy required for gear alignment, Bed cannot be supplied separately and can only be sent as a unit, Arm and Bed assembled.




Use
Cat. 2020 (15x1)
Needles



List of Parts—Machine No. 403A

Handwritten: 172011 172012 172013 172014 172015



NOTE: Set of Mated Gears or Individual Gears are not furnished. Supplied only when repairs are made at the factory.

