



SINGER
500A

List of Parts—Machine No. 500A

ATTACHMENT SET 161743

81200	Binder
161133	Tube of Oil
161166	Zipper Foot
161168	Button Foot
161172	Seam Guide
161195	Hemmer Foot
161200	Attachment Box
161276	Lint Brush
161294	Screwdriver (IG)
161295	Screwdriver (SM)
161561	Ruffler
163483	Special Purpose Foot
170071-001	Presser Foot
172187	Fashion Disc 2
172189	Fashion Disc 3
172190	Fashion Disc 4
172191	Fashion Disc 5
172336	Bobbin (Plastic) (4)
174529	Throat Plate
2020(15x1)	Needles 14 (3) 16 (3)
21184	Instruction Book

List of Parts—Machine No. 500A



500A
 Part #
 605705101

Electrical Parts

Machine No. 500A1

Machine No. 500A6

Machine No. 500A4

